

## **Partition & Format of SPIO (HDD)**

\* Caution: Install the driver before "Partition & Format".

### 1) For windows 98/ME

l The way to Fdisk and Format with new Hard disk (with one drive)

- a. Install the driver before connect the product to computer
- b. Install the driver – Program – MS DOS
- c. Type "Fdisk" directly and press the "Enter"
- d. Find the question "will you use the Big Disk support function?".
- e. Type "Y" and press "Enter".
- f. Choose the "NO.5 change the present hard disk drive" among the Fdisk options.
- g. Choose the last number in change the "Hard disk drive" - Type the Hard disk number of Fdisk in "Type the Hard disk number" – press the "Enter"
- h. Press "ESC" – choose the "NO 1. select the logic dos driver. or partition" among the Fdisk option items – Type "NO.1" – Press "Enter"
- i. After finish the "No formation test, you can find the message" will you use the whole capacity for basic Dos partition".
- j. The type "Y" and press the "Enter"
- k. Type "Needed capacity or %" directly and press "Enter". –After finish the No formation test again. You can find the message "select basic Dos partition, the drive word is changed or added".
- l. Then press "ESC" to return to Fdisk option.
- m. Press "ESC" – Find the message "Re-start the computer" – Press "ESC" again – IF you find press "EXIT" to return to window.
- n. Separate SPIO from the computer.
- o. Connect the SPIO to USB port in computer, again
- p. The " Drive word" will be created in "My computer"
- q. Choose the drive – press the right side of the Mouse and do the Format(M)

### 2) For windows 2000/XP

Click the "My computer" with right side of Mouse in the screen and click "Manage".  
Click Disk Management from Storage.

- a. Click the drive of "Not allotted" in Disk management with the right side of the mouse. – Carry out the "Making partition".
- b. After complete the "Making partition magician" click the "Next"
- c. After check if the "main partition (P)" is selected in kinds of partition. Then click the "Next"
- d. Type the needed capacity at "Disk space" in partition size. Then click "Next"
- e. If the drive word is allotted, click "Next"
- f. Choose one from the kind of file system (NTFS, FAT32) and check quick format.

\* Caution: The "NTFS File system" will be recognized only in "windows 2000/XP" If you want it use with "windows 98/ ME", please choose "FAT32". In case of larger size of HDD you have to partition 2 or 3 part for "FAT32".

- g. After the Format, click the "Finish"

### 3) For MAC

\* Caution: 1) Over MAC OS 8.6

2) The Hard disk that doesn't have Fdisk and Format can not be recognized.  
Install the driver, first then initialization.

3) If you want to use it in MAC and IBM, please carry out the Fdisk and Format in IBM computer.

- a. First install the "Install ISD storage driver" in USB folder of MAC OS folder. That is in offered CD
- b. Re-booting the computer.
- c. Connect the USB cable to SPIO.
- d. Connect the opposite side of USB cable to USB port in computer.
- e. The driver Icon will be created in the screen.

P&FSPIO12092002